



### FIELD INSTALLATION – POLYETHYLENE WRAP

**NOTE:**

- STEP 1– PLACE TUBE OF POLYETHYLENE MATERIAL ON PIPE PRIOR TO LOWERING IT INTO TRENCH.
- STEP 2– PULL THE TUBE OVER THE LENGTH OF PIPE. TAPE TUBE TO PIPE AT JOINT. FOLD MATERIAL AROUND THE ADJACENT SPIGOT END AND WRAP WITH TAPE TO HOLD THE PLASTIC TUBE IN PLACE.
- STEP 3– OVERLAP FIRST TUBE WITH ADJACENT TUBE AND SECURE WITH PLASTIC ADHESIVE TAPE. THE POLYETHYLENE TUBE MATERIAL COVERING THE PIPE SHALL BE LOOSE. EXCESS MATERIAL SHALL BE NEATLY DRAWN UP AROUND THE PIPE BARREL, FOLDED ON TOP OF PIPE AND TAPE IN PLACE.

REVISED 10-08-03 | CADD DRAWING BY GTS CONSULTANTS, INC.

DATE: JAN. 1991

DRAWN: G.G.&J.T.R.

SCALE: NONE

LAKWOOD TOWNSHIP  
MUNICIPAL UTILITIES AUTHORITY

POLYETHYLENE  
ENCASEMENT