

THE FOLLOWING SHALL BE THE MINIMUM NUMBER OF STEPS TAKEN TO TEMPORARILY ABANDON AN EXISTING WATER SERVICE. THE CONTRACTOR SHALL TAKE ANY & ALL ADDITIONAL STEPS NECESSARY TO ENSURE WORKER & PUBLIC SAFETY AND TO RETAIN THE INTEGRITY OF THE EXISTING WATER MAIN & SERVICE LINE AND ANY AND ALL ADDITIONAL UNDERGROUND UTILITIES THAT MAY BE ENCOUNTERED. ALL WORK SHALL BE PERFORMED IN ACCORDANCE WITH ALL APPLICABLE CURRENT STANDARDS, RULES AND REGULATIONS PUT FORTH BY ALL THE APPLICABLE GOVERNMENTAL AGENCIES AND ENTITIES.

- THE WORK SITE(S) SHALL BE SECURED FROM PUBLIC ACCESS VIA FENCING, BARRIERS, TRAFFIC CONTROL DEVICES/PERSONEL, ETC. THESE MEASURES SHALL BE TAILORED TO MEET SITE—SPECIFIC CONDITIONS.
- 2. TURN OFF THE WATER SERVICE AT THE EXISTING CURB STOP.
- SAW-CUT AND REMOVE ANY ASPHALT OR CONCRETE PAVEMENT ABOVE THE LOCATION WHERE THE WATER SERVICE LINE CONNECTS TO THE BUILDING SIDE OF THE CURB STOP.
- 4. EXCAVATE DOWN TO A POINT JUST ABOVE THE CURB STOP.
- 5. HAND DIG DOWN TO EXPOSE THE CURB STOP AND THE SERVICE LINE BEING CAREFUL NOT TO EXCAVATE BELOW THE CURB STOP.
- 6. CUT THE WATER SERVICE LINE 12" FROM THE BUILDING SIDE OF THE CURB STOP AND CRIMP BOTH ENDS.
- 7. REMOVE THE SHORT WATER SERVICE LINE "TAIL" PIECE FROM THE CURB STOP.
- 8. SEAL THE BUILDING SIDE OF THE CURB STOP WITH A COPPER DISK OR PLUG AS SPECIFIED BY THE MANUFACTURER OF THE CURB STOP AND IN ACCORDANCE WITH THE SPECIFICATIONS PROVIDED BY THE CURB STOP AND DISK/PLUG MANUFACTURERS.
- 9. REATTACH THE SHORT WATER SERVICE LINE "TAIL" PIECE OVER THE INSTALLED DISK/PLUG.
- 10. BACKFILL AND COMPACT THE EXCAVATION(S) IN 6 INCH LIFTS IN ACCORDANCE WITH THE L.T.M.U.A. STANDARDS.
- 11. INSTALL A 5' LONG BLUE CARSONITE MARKER POST DIRECTLY OVER THE CUT IN THE SERVICE LINE SUCH THAT 4' OF THE POST IS BURIED AND 1' OF THE POST IS LEFT EXPOSED ABOVE THE FINAL GROUND SURFACE.
- 12. REPAIR ANY REMOVED PAVEMENT MATERIALS ACCORDING TO THE APPLICABLE CURRENT STANDARDS.
- 13. REMOVE ALL TEMPORARY MEASURES INSTALLED IN ACCORDANCE WITH STEP 1 ABOVE.